



FIG.1A




FIG.1B




FIG.2A




FIG.2B




FIG.3B




FIG.3A




FIG.3C




FIG.4




FIG.5




FIG.6




FIG.7





FIG.8A




Welcome to Photo Net Service!

The camera number of this page is NETDE1025.
This camera was collected on August 20, 1999
at XYZ Shop, ABC Inc.
Click OK if correct.

OK BACK

FIG.8B



Input password.

OK CANCEL

FIG. 9

SST PHOTO NET SERVICE

Connect to the network from your home PC, and input your receipt number and password.




FIG.10

AREA: OKINAWA




FIG.11A




FIG.11B




FIG.12




FIG.13

COUNTER PART NODE TRANSMITTING A
SIGNAL IN ACCORDANCE WITH IEEE 1394




FIG.14A

WARNING

HISTORY SHOWS DISASSMEBLY OF THE CAMERA. SO
THAT IMAGE DISPLAY IS IMPOSSIBLE

PAYMENT OF CHARGES NECESSARY TO OBTAIN IMAGE
DISPLAY.

NO DISPLAY

CHARGE AND DISPLAY

FIG.14B

WARNING

HISTORY SHOWS UNAUTHOURIZED CONNECTION OF
THE CAMERA, SO THAT IMAGE DISPLAY IS IMPOSSIBLE.

PAYMENT OF CHARGES IS NECESSARY TO DISPLAY IMAGE.

NO DISPLAY

CHARGE AND DISPLAY

FIG. 15




FIG. 16




FIG. 17




FIG. 18A




FIG. 18B




FIG. 19




FIG. 20 PRIOR ART




FIG. 21 PRIOR ART




FIG. 22 PRIOR ART

